

## **Kubota RTV**

## X- series Coast Plug

## Installation Instructions

- 1. Locate plug (A) by looking under the right rear side of the bed.
- 2. Remove plug (A) and discard.
- 3. Install new Coast Plug in the place of plug (A).

Installation complete.

